





Illus. No.	Part No.	DESCRIPTION
1	9758377	Literature Parts Installation Instructions Anti-Tip Template 9757142 English/Spanish 9757143 English/French 9758363 Use & Care Guide 9756997 Tech Sheet 3191638 Safer Cooking Tips
2	3149191	Spring, Locator
3	3196170	Screw
4		Cooktop 9762045 White 9762042 Black 9762037 Black Stainless
5	8523739	Light, Indicator (Hot Surface)
6	8523741	Bracket, Ind Light Element, Surface
7	9757027	2500/1000 W - LF
	8273994	1200 W - LR
	8273993	1800 W - RF
	9757031	1800/800 W - RR
	9757028	100 W - CR
9		Bracket, Element 8272791 (2) 8273720 (1)
10	3196169	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: KERI203PWH2, KERI203PBL2, KERI203PBS2
(White) (Black) (Black Stainless)



Illus. No.	Part No.	DESCRIPTION
1	9756959	White Left Hand
	9756958	White Right Hand
	9756961	Black Left Hand
	9756960	Black Right Hand
2	9762098	White
	9762100	Black
3	9756724	White
	9756732	Black
	9756725	Black Stainless


Illus. No.	Part No.	DESCRIPTION
4	9757030	LF (Dual)
	3148953	RF/RR (Green)
	3148952	LR (Yellow)
	8523266	Light, Indicator
5	3196068	Lens, Light (2)
7	9756941	White
	9756943	Black
8	9756934	Shield, Heat
10	9756999	Cover, Rear
	9758366WH	White
	9758366BL	Black

Illus. No.	Part No.	DESCRIPTION
12	9756548	Control, Range
13	3196178	Screw
15	9757406WH	White
	9757406BL	Black
16	3400882	Screw
17	9758319	Cover, Rear (Console)
	9758352	White
18	9758354	Black
	9758355	Cashmere Metallic
19	9761077	Membrane, Insert

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CHASSIS PARTS

For Models: KERI203PWH2, KERI203PBL2, KERI203PBS2
(White) (Black) (Black Stainless)




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

For Models: KERI203PWH2, KERI203PBL2, KERI203PBS2
(White) (Black) (Black Stainless)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: KERI203PWH2, KERI203PBL2, KERI203PBS2
(White) (Black) (Black Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS


For Models: KERI203PWH2, KERI203PBL2, KERI203PBS2
(White) (Black) (Black Stainless)

Illus. No.	Part No.	DESCRIPTION
1		Trim, Door Top
	9756965	White
	9756967	Black
	9758314	Black Stainless
2	8534065	Screw
3		Handle, Door
	9758293	White
	9782649	Black
	9758294	Black Stainless
4	3186292	Liner, Door
5	8522414	Seal, Window
6	9758162	Glass, Inner (2)
7	3186289	Frame, Glass
8	8272618	Insulation, Door
9	3186297	Retainer, Insul.
10	8053807	Hinge, Door
11		Glass, Outer Door
	9762127	White
	9762129	Black
	9756435	Stainless Model
12		Trim, Side
	8523172	White Left Hand
	8523166	White Right Hand
	8523171	Black Left Hand
	8523165	Black Right Hand
13	3196160	Screw
14		Trim, Lower
	8523175	White
	8523177	Black
	8523180	Stainless
15	3196025	Clip, Glass (4)
18	3196161	Screw
19	3196925	Clip, Door Stop
20	3196165	Screw
22	3196794	Bracket, Window(2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DRAWER & BROILER PARTS

For Models: KERI203PWH2, KERI203PBL2, KERI203PBS2
(White) (Black) (Black Stainless)



Illus. No.	Part No.	DESCRIPTION
1	3195710	Rack, Oven (3)
2	3195996	Grill, Broiler
3	3196076	Pan, Broiler
4	8272605	Drawer, Storage
5	9758200	Bracket, Drawer(2)
6		Rivet, Push (2)
	3196814	White
	3196813	Black

Illus. No.	Part No.	DESCRIPTION
7		Panel, Drawer Frnt
	9756325	White
	9756327	Black
	9756328	Stainless
8		Handle, Drawer
	9756952WH	White
	9756952BL	Black
9	3181534	Rack, Roasting
10	3196168	Screw

Illus. No.	Part No.	DESCRIPTION
11		Rail Assy, Drawer
	8274191	Right
	8274190	Left
12	9756711	Heat Shield
15	8522669	Spacer, Glide
16	9751138	Roller (2)
17	487939	Nut (2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: KERI203PWH2, KERI203PBL2, KERI203PBS2
(White) (Black) (Black Stainless)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

Following Parts Not Illustrated

SPLICING WIRES--25FT.

LENGTH

242828	Wire, Black	12 Ga. 150° c
242821	Wire, Blue	14 Ga. 150°c
242822	Wire, Brown	14 Ga. 150°c
242830	Wire, Brown	14 Ga. 200°c
242823	Wire, Green	14 Ga. 150°c
242824	Wire, Orange	14 Ga. 150°c
242825	Wire, Red	14 Ga. 150°c
242831	Wire, Red	14 Ga. 200°c
242827	Wire, Yellow	14 Ga. 150°c

REFINISHING MATERIAL

799832	Kit, Porcelain Repair (White)
242756	Touch-Up Self-Clean(1/2 Pt)
261582	Grease

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

INSULATION

261514	Insulation, Fiberglass (1-1/2" x 24" x 120")
240132	Insulation, Fiberglass (2-1/2" x 22" x 120")
313660	Clip, Ground Wire
3196173	Screw

PAINT, TOUCH-UP (1/2oz.)

72017	White
4392899	Biscuit
511873	White Porcelain (2 Oz.)

PAINT, PRESSURIZED SPRAY (12 oz.)

350930	White
4392901	Biscuit
285006	Superior Black
206922	Primer (White)

PAINT, BULK (1 qt.)

799344	White (Uncut)
4392900	Biscuit (Uncut)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

ACCESSORY PARTS

241430	Foil, Aluminum Oven (18" x 25')
4456147	Cleaner, Glass
2261590	Cleaner (Stainless Steel)

ANTI-TIP KIT

9757976	Anti-Tip Kit
---------	--------------

WIRING HARNESS PARTS

9757044	Harness, Oven
9756745	Harness, Cooktop (Left w/Dual)
9757332	Harness, Cooktop (Right w/ wm)
9757338	Harness, Console
9757339	Harness, Bake Element (Hidden)
3196520	Clip, Wire Harness
9758174	Harness, Wire (Door Switch)
8524132	Shield, Wiring (2)
8523279	Wire, Ground
3196154	Screw, Ground

Miscellaneous

3196897	Pin Kit-Dr Removal
---------	--------------------